


**HRPC2**

## Accessing the Features Menu

Accessing the features menu for the camera can only be done while using a computer that is on the same network as your HomeRemote Pro Gateway. You cannot access the menu remotely via the web. To access the menu while using a "local" computer follow these steps below:

- a) Log on to your HomeRemote Pro account and enter your login information.  
<http://pro.homeremote.net>



- b) When your account page loads click **Access Home**



- c) From the Home Status page click the **Camera Setup** link located on left sidebar



- d) Locate your configured camera and click **Configure this Camera Locally**. Enter the default login info when the pop up appears:

Username: **admin**  
 Password: **1234**



- e) A new window will appear with the **Feature Menu** for your camera. It is from this menu that you will navigate to most of the features for your camera.



## Video Settings

To adjust the video settings of your camera, click **Video Settings** from the feature menu.

### Video Settings Features

**Resolution:** Adjusts the pixel count and overall size of your image. It is recommended not to go over 320x240 px as the HomeRemote Pro server viewer only supports up to 320x240 px. However, 640x480 px may be used for recording purposes.

**Image Quality:** Adjusts how detailed your video is. It is recommended that this setting remain at "Normal" however if you have a fast Internet connection you can try a higher quality setting.

**Max Frame Rate:** The amount of frame sent out per second by your camera determines how smooth the video is. This again is limited by your internet connection speed at your house. It is recommended to leave this setting at 16fps.

**Frequency:** Adjust viewing quality under specific fluorescent lighting conditions.

**Image Setting:** In addition to the image quality and video stream you can also adjust the **brightness**, **contrast** and **saturation** of your picture as well as the orientation of the image.



Click **Apply** to enable any changes made to the camera.

## Recordings: Schedules and Triggers


To set your recording and triggering settings, select **Recordings, Snapshot Schedules and Triggers** from the feature menu

- a) **File Location:** Create a subfolder to store recorded files. Set a time limit for each recorded file.

- b) **Scheduled Recordings:** To set schedules for your recordings you must first **create a profile** (such as "vacation"). When the profile is added, highlight it to set the specific recording schedule.

- c) **Motion Detection Triggers:** To enable recording when motion is detected, select **Enable** then select a schedule for when you wish this feature to be active and then select a type of recording output. You can select all if outputs if you wish.

- d) **Setup Email, FTP and Network Storage Settings:** The HRPC2 has a large array of recording options. To record to each type of storage output, you must first **enable** it then select a schedule profile for when you wish that specific output to be active. You can also customize the recording time intervals for each recorded file.



## Recording Output Setup

To setup your recording options and storage locations click **Recording and Snapshot Settings** from the features menu


The HomeRemote Pro Camera with Night Vision can record images or video to FTP servers, email addresses, and network storage devices. This page will allow you to provide the setup details of each recording storage output you wish to use. Make sure to "test" your settings before applying the configurations to ensure that you have set them up correctly.



## Motion Detection Settings

The HRPC2 features an advanced two sensor motion detector. To configure the settings for the detector, select **Motion Detector Settings** from the feature menu.

Select a **window number** from the right drop down menu and click **Enable** to begin configuring that motion detection sensor. A red box will appear. Use your mouse to move it and enlarge it until it covers the area that you wish to detect for motion. **Provide a name** for the sensor (such as door) and **set the sensitivity** level of the detector. **Click save** when you are done. You can **repeat these steps** if you wish to set a second motion detection window.



## Other System Options

The HRPC2 Camera allows you to configure a host of other features, such as **changing your login password**, **recording to the USB port** on the device and **enabling Night Mode** to enable night vision LEDs.

The **System Tools** section of your feature menu allows you to configure several system and security features of your camera. From here you can:

- Adjust the **LED light** on actual camera, on or off, to hide the camera from intruders
- Reboot the camera** in the event that a reset is necessary
- Update the software**, when new features are available from the HomeRemote Pro Servers

The features menu provides access to your current **Camera Information** which displays your network settings, Product Key and other detailed setup information.

Navigate the entire feature menu to access all options provided by the HRPC2.



## Recording and Viewing Software (Located on Included CD)

To record live video from your HomeRemote Pro Camera directly to your PC, it is necessary that you install the included Recording and Viewing Software located on the Software CD (only for Windows-based PC's). Follow the steps below to install and use the Recording and Viewing Software:

### Software Installation

- a) Insert the included Software CD into your PC's CD/DVD drive



- b) When the CD menu page appears select **Recording and Viewing Software** and follow the steps to install the software

- c) When the installation has completed, select the **software icon** located on your computer's desktop to launch the program:



If you cannot find this icon, click the **Start** button in the lower left hand corner, select **Programs**, select **HomeRemote Pro Camera**, then select **HomeRemote Pro Camera Software**, To access the Recording software select **HomeRemote Pro Recording and Viewing Software 2**

### Using the Recording and Viewing Software

The viewing software supports viewing of up to 16 HRPC2 HomeRemote Pro Cameras. This Feature Guide will give you a brief overview of your software. For a more detailed explanation please refer to the online users manual.

### Associating your Camera to the Software

- a) Click the **Settings icon** on the top left corner of the software
- b) When the camera setting page appears, select **Add Camera**
- c) If your camera is connected to your network it should appear on the list. Highlights it and click **Add Camera**. If it is not listed click **Search**.
- d) You will be asked to enter the username and password for the camera which by default settings is: User: **admin** PW: **1234**
- e) Click the **Settings Icon** again and you should be returned to the main interface.

### Using the Control Panel

- a) **Settings:** Add new cameras, delete cameras, save settings, load settings all from the main settings page
- b) **Playback:** Plays back recorded files from the camera that are stored on your PC
- c) **Lock:** Locks all functions on the HomeRemote Pro Recording and Viewing Software
- d) **Record All:** Begin recording from all cameras simultaneously
- e) **Main View:** The main window for viewing cameras
- f) **Viewer Settings:** Change the size and number of cameras in the viewing windows. View up to 16 cameras simultaneously
- g) **Cycle View:** Cycle through different camera views one at a time
- h) **Snapshot:** Take a snapshot from a camera
- i) **Talk:** If a speaker is connected to the HRPC2 this button allows you to talk through the speaker
- j) **Listen:** Listen to incoming audio on the HRPC2
- k) **Record:** Begin recording video from one camera
- l) **Camera List:** Shows all active cameras in your system (does not work with HRPC1)

